

## 40 C.F.R. § 98.303

## Calculating GHG emissions.

(a) Calculate the annual SF<sub>6</sub> and PFC emissions using the mass-balance approach in Equation DD−1 of this section:

```
User Emissions = (Decrease in SF_6 Inventory) + (Acquisitions of SF_6) - (Disbursements of SF_6) - (Net Increase in Total Nameplate Capacity of Equipment Operated)

(Eq. DD-1)
```

## where:

Decrease in SF<sub>6</sub> Inventory = (pounds of SF<sub>6</sub> stored in containers, but not in energized equipment, at the beginning of the year) – (pounds of SF<sub>6</sub> stored in containers, but not in energized equipment, at the end of the year). Acquisitions of SF<sub>6</sub> = (pounds of SF<sub>6</sub> purchased from chemical producers or distributors in bulk) + (pounds of SF<sub>6</sub> purchased from equipment manufacturers or distributors with or inside equipment, including hermetically sealed–pressure switchgear) + (pounds of SF<sub>6</sub> returned to facility after off-site recycling). Disbursements of SF<sub>6</sub> = (pounds of SF<sub>6</sub> in bulk and contained in equipment that is sold to other entities) + (pounds of SF<sub>6</sub> returned to suppliers) + (pounds of SF<sub>6</sub> sent off site for recycling) + (pounds of SF<sub>6</sub> sent off-site for destruction). Net Increase in Total Nameplate Capacity of Equipment Operated = (The Nameplate Capacity of new equipment in pounds, including hermetically sealed–pressure switchgear) – (Nameplate Capacity of retiring equipment in pounds, including hermetically sealed–pressure switchgear). (Note that Nameplate Capacity refers to the full and proper charge of equipment rather than to the actual charge, which may reflect leakage).

This document is only available to subscribers. Please log in or purchase access.

Purchase Login