
40 C.F.R. § 98.423

Calculating CO₂ supply.

(a) Except as allowed in paragraph (b) of this section, calculate the annual mass of CO₂ captured, extracted, imported, or exported through each flow meter in accordance with the procedures specified in either paragraph (a)(1) or (a)(2) of this section. If multiple flow meters are used, you shall calculate the annual mass of CO₂ for all flow meters according to the procedures specified in paragraph (a)(3) of this section.

(1) For each mass flow meter, you shall calculate quarterly the mass of CO₂ in a CO₂ stream in metric tons by multiplying the mass flow by the composition data, according to Equation PP-1 of this section. Mass flow and composition data measurements shall be made in accordance with § 98.424 of this subpart.

$$CO_{2,u} = \sum_{p=1}^4 Q_{p,u} * C_{CO_2,p,u} \quad (\text{Eq. PP-1})$$

Where:

CO_{2,u} = Annual mass of CO₂ (metric tons) through flow meter u. C_{CO₂,p,u} = Quarterly CO₂ concentration measurement in flow for flow meter u in quarter p (wt. %CO₂). Q_{p,u} = Quarterly mass flow rate measurement for flow meter u in quarter p (metric tons). p = Quarter of the year. u = Flow meter.

(2) For each volumetric flow meter, you shall calculate quarterly the mass of CO₂ in a CO₂ stream in metric tons by multiplying the volumetric flow by the concentration and density data, according to Equation PP-2 of this section. Volumetric flow, concentration and density data measurements shall be made in accordance with § 98.424 of this section.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)