

## 40 C.F.R. § 1060.510

---

### How do I test EPA Low-Emission Fuel Lines for permeation emissions?

---

For EPA Low-Emission Fuel Lines, measure emissions according to SAE J2260, which is incorporated by reference in § 1060.810.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)