

40 C.F.R. § 1065.325

Intake-flow calibration.

- (a) Calibrate intake-air flow meters upon initial installation. Follow the instrument manufacturer's instructions and use good engineering judgment to repeat the calibration. We recommend using a calibration subsonic venturi, ultrasonic flow meter or laminar flow element. We recommend using calibration reference quantities that are NIST-traceable within $\pm 0.5\%$ uncertainty.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)