

---

## 40 C.F.R. § 761.125

---

### Requirements for PCB spill cleanup.

---

(a) *General.* Unless expressly limited, the reporting, disposal, and precleanup sampling requirements in paragraphs (a) (1) through (3) of this section apply to all spills of PCBs at concentrations of 50 ppm or greater which are subject to decontamination requirements under TSCA, including those spills listed under § 761.120(b) which are excluded from the cleanup standards at paragraphs (b) and (c) of this section.

(1) *Reporting requirements.* The reporting in paragraphs (a)(1) (i) through (iv) of this section is required in addition to applicable reporting requirements under the Clean Water Act (CWA) or the Comprehensive Environmental Response Compensation and Liability Act of 1980 (CERCLA). For example, under the National Contingency Plan all spills involving 1 pound or more by weight of PCBs must currently be reported to the National Response Center (1-800-424-8802). The requirements in paragraphs (a)(1) (i) through (iv) of this section are designed to be consistent with existing reporting requirements to the extent possible so as to minimize reporting burdens on governments as well as the regulated community.

(i) Where a spill directly contaminates surface water, sewers, or drinking water supplies, as discussed under § 761.120(d), the responsible party shall notify the appropriate EPA regional office and obtain guidance for appropriate cleanup measures in the shortest possible time after discovery, but in no case later than 24 hours after discovery.

(ii) Where a spill directly contaminates grazing lands or vegetable gardens, as discussed under § 761.120(d), the responsible party shall notify the appropriate EPA regional office and proceed with the immediate requirements specified under paragraph (b) or (c) of this section, depending on the source of the spill, in the shortest possible time after discovery, but in no case later than 24 hours after discovery.

(iii) Where a spill exceeds 10 pounds of PCBs by weight and is not addressed in paragraph (a)(1) (i) or (ii) of this section, the responsible party will notify the appropriate EPA regional office and proceed to decontaminate the spill area in accordance with this TSCA policy in the shortest possible time after discovery, but in no case later than 24 hours after discovery.

(iv) Spills of 10 pounds or less, which are not addressed in paragraph (a)(1) (i) or (ii) of this section, must be cleaned up in accordance with this policy (in order to avoid EPA enforcement liability), but notification of EPA is not required.

(2) *Disposal of cleanup debris and materials.* All concentrated soils, solvents, rags, and other materials resulting from the cleanup of PCBs under this policy shall be properly stored, labeled, and disposed of in accordance with the provisions of Subpart D of this part, except that such materials shall not be disposed of in a hazardous waste landfill permitted by EPA under section 3005 of RCRA or by a State or territory authorized under section 3006 of RCRA pursuant to § 761.61(b)(2)(ii)(A).

(3) *Determination of spill boundaries in the absence of visible traces.* For spills where there are insufficient visible

---

traces yet there is evidence of a leak or spill, the boundaries of the spill are to be determined by using a statistically based sampling scheme.

(b) *Requirements for cleanup of low-concentration spills which involve less than 1 pound of PCBs by weight (less than 270 gallons of untested mineral oil)*—(1) *Decontamination requirements.* Spills of less than 270 gallons of untested mineral oil, low-concentration PCBs, as defined under § 761.123, which involve less than 1 pound of PCBs by weight (e.g., less than 270 gallons of untested mineral oil containing less than 500 ppm PCBs) shall be cleaned in the following manner:

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)