

40 C.F.R. § 761.253

Chemical analysis.

- (a) Extract PCBs from the standard wipe sample collection medium and clean-up the extracted PCBs in accordance with either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)