
40 C.F.R. § 761.265

Sampling bulk PCB remediation waste and porous surfaces.

- (a) Use a grid interval of 3 meters and the procedures in §§ 761.283 and 761.286 to sample bulk PCB remediation waste that is not in a container and porous surfaces.
- (b) Use the following procedures to sample bulk PCB remediation waste that is in a single container.
 - (1) Use a core sampler to collect a minimum of one core sample for the entire depth of the waste at the center of the container. Collect a minimum of 50 cm of waste for analysis.

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)