

# 40 C.F.R. § 761.360

---

## Background.

---

The double wash/rinse procedure is used to quickly and effectively remove PCBs on surfaces. It is important to select and use the proper cleanup equipment, to conduct the procedure correctly so as not to redistribute PCBs, and to comply with disposal requirements for all cleanup materials.

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)