

## 40 C.F.R. § 761.366

---

### Cleanup equipment.

---

- (a) Use scrubbers and absorbent pads that are not dissolved by the solvents or cleaners used, and that do not shred, crumble, or leave visible fragments on the surface. Scrubbers and absorbent pads used to wash contaminated surfaces must not be reused. Scrubbers and absorbent pads for rinsing must not contain  $\geq 2$  ppm PCBs. Scrubbers and absorbent pads used in the second rinse of contaminated surfaces may be reused to wash contaminated surfaces.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)