

## 40 C.F.R. § 761.372

---

### Specific requirements for relatively clean surfaces.

---

For surfaces that do not appear dusty or grimy before a spill, such as glass, automobile surfaces, newly-poured concrete, and desk tops, use the double wash/rinse procedures in this section.

- (a) *First wash.* Cover the entire surface with organic solvent in which PCBs are soluble to at least 5 percent by weight. Contain and collect any runoff solvent for disposal. Scrub rough surfaces with a scrub brush or disposable scrubbing pad and solvent such that each 900 cm (1 square foot) of the surface is always very wet for 1 minute. Wipe smooth surfaces with a solvent-soaked, disposable absorbent pad such that each 900 cm (1 square foot) is wiped for 1 minute. Any surface <1 square foot shall also be wiped for 1 minute. Wipe, mop, and/or sorb the solvent onto absorbent material until no visible traces of the solvent remain.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)