

## 40 C.F.R. § 761.392

---

### Preparing validation study samples.

---

(a)

(1) To validate a procedure to decontaminate a surface contaminated with a spill from liquid of a known concentration, contaminate (spike) the surface to be used in the validation study as follows:

(i) Use a spiking solution made of PCBs mixed with a solvent to contaminate clean surfaces. Clean surfaces are surfaces having PCB surface concentrations  $<1 \mu\text{g}/100 \text{ cm}$  before intentionally contaminating the surface.

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)