
40 C.F.R. § 63.7323

What procedures must I use to establish operating limits?

- (a) For a venturi scrubber applied to pushing emissions from a coke oven battery, you must establish site-specific operating limits for pressure drop and scrubber water flow rate according to the procedures in paragraphs (a)(1) and (2) of this section.
- (1) Using the continuous parameter monitoring systems (CPMS) required in § 63.7330(b), measure and record the pressure drop and scrubber water flow rate for each particulate matter test run during periods of pushing. A minimum of one pressure drop measurement and one scrubber water flow rate measurement must be obtained for each push.
- (2) Compute and record the average pressure drop and scrubber water flow rate for each test run. Your operating limits are the lowest average pressure drop and scrubber water flow rate values recorded during any of the three runs that meet the applicable emission limit.
- (b) For a hot water scrubber applied to pushing emissions from a coke oven battery, you must establish site-specific operating limits for water pressure and water temperature according to the procedures in paragraphs (b)(1) and (2) of this section.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)