

## 40 C.F.R. § 63.7943

## How do I determine the average VOHAP concentration of my remediation material?

- (a) General requirements. You must determine the average total VOHAP concentration of a remediation material using either direct measurement as specified in paragraph (b) of this section or by knowledge as specified in paragraph (c) of this section. These methods may be used to determine the average VOHAP concentration of any material listed in (a)(1) through (3) of this section.
- (1) A single remediation material stream; or
- (2) Two or more remediation material streams that are combined prior to, or within, a remediation material management unit or treatment process; or
- (3) Remediation material that is combined with one or more non-remediation material streams prior to, or within, a remediation material management unit or treatment process.
- (b) Direct measurement. To determine the average total VOHAP concentration of a remediation material using direct measurement, you must use the procedures in paragraphs (b)(1) through (3) of this section.
- (1) Sampling. Samples of each material stream must be collected from the container, pipeline, or other device used to deliver each material stream prior to entering the remediation material management unit or treatment process in a manner such that volatilization of organics contained in the sample is minimized and an adequately representative sample is collected and maintained for analysis by the selected method.

This document is only available to subscribers. Please log in or purchase access.

Purchase Login