

40 C.F.R. § 63.7947

What are my monitoring alternatives?

- (a) As an alternative to the parametric monitoring required in this subpart, you may install, calibrate, and operate a continuous emission monitoring system (CEMS) to measure the control device outlet total organic emissions or organic HAP emissions concentration.
- (1) The CEMS used on combustion control devices must include a diluent gas monitoring system (for O₂ or CO₂) with the pollutant monitoring system in order to correct for dilution (*e.g.*, to 0 percent excess air).

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)