

40 C.F.R. § 1090.1340

Preparing a hand blend from BOB.

- (a) If you produce or import BOB and instruct downstream blenders to add oxygenate, you must meet the requirements of this subpart by blending oxygenate that reflects the anticipated sulfur content and benzene content of the oxygenate for blending into a BOB sample. To do this, prepare each hand blend by adding oxygenate to the BOB sample in a way that corresponds to your instructions to downstream blenders for the sampled batch of fuel. Prepare a hand blend as follows:

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)