

40 C.F.R. § 60.1220

What happens to the emission limits during periods of startup, shutdown, and malfunction?

- (a) The emission limits of this subpart apply at all times except during periods of municipal waste combustion unit startup, shutdown, or malfunction.

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)