

## 40 C.F.R. § 60.1810

---

### How do I monitor the load of my municipal waste combustion unit?

---

(a) If your municipal waste combustion unit generates steam, you must install, calibrate, maintain, and operate a steam flowmeter or a feed water flowmeter and meet five requirements:

- (1) Continuously measure and record the measurements of steam (or feed water) in kilograms (or pounds) per hour.
- (2) Calculate your steam (or feed water) flow in 4-hour block averages.

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)