

## 40 C.F.R. § 1051.705

---

### How do I average emission levels?

---

- (a) As specified in subpart B of this part, certify each vehicle to an FEL, subject to the FEL caps in subpart B of this part.
- (b) Calculate a preliminary average emission level according to § 1051.720 for each averaging set using projected U.S.-directed production volumes from your application for certification, excluding vehicles described in § 1051.701(d)(4).

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)