

40 C.F.R. § 1065.120

Fuel properties and fuel temperature and pressure.

- (a) Use fuels as specified in the standard-setting part, or as specified in subpart H of this part if fuels are not specified in the standard-setting part.
- (b) If the engine manufacturer specifies fuel temperature and pressure tolerances and the location where they are to be measured, then measure the fuel temperature and pressure at the specified location to show that you are within these tolerances throughout testing.

This document is only available to subscribers. Please log in or purchase access.

Purchase Login