

40 C.F.R. § 1065.930

Engine starting, restarting, and shutdown.

Unless the standard-setting part specifies otherwise, start, restart, and shut down the test engine for field testing as follows:

- (a) Start or restart the engine as described in the owners manual.
- (b) If the engine does not start after 15 seconds of cranking, stop cranking and determine the reason it failed to start. However, you may crank the engine longer than 15 seconds, as long as the owners manual or the service-repair manual describes the longer cranking time as normal.

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)