

40 C.F.R. § 279.1

Definitions.

Terms that are defined in §§ 260.10, 261.1, and 280.12 of this chapter have the same meanings when used in this part.

Aboveground tank means a tank used to store or process used oil that is not an underground storage tank as defined in § 280.12 of this chapter.

Container means any portable device in which a material is stored, transported, treated, disposed of, or otherwise handled.

Do-it-yourselfer used oil collection center means any site or facility that accepts/aggregates and stores used oil collected only from household do-it-yourselfers.

Existing tank means a tank that is used for the storage or processing of used oil and that is in operation, or for which installation has commenced on or prior to the effective date of the authorized used oil program for the State in which the tank is located. Installation will be considered to have commenced if the owner or operator has obtained all federal, state, and local approvals or permits necessary to begin installation of the tank and if either

- (1) A continuous on-site installation program has begun, or

- (2) The owner or operator has entered into contractual obligations—which cannot be canceled or modified without substantial loss—for installation of the tank to be completed within a reasonable time.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)