

40 C.F.R. § 98.143

Calculating GHG emissions.

You must calculate and report the annual process CO₂ emissions from each continuous glass melting furnace using the procedure in paragraphs (a) through (c) of this section.

- (a) For each continuous glass melting furnace that meets the conditions specified in § 98.33(b)(4)(ii) or (iii), you must calculate and report under this subpart the combined process and combustion CO₂ emissions by operating and maintaining a CEMS to measure CO₂ emissions according to the Tier 4 Calculation Methodology specified in § 98.33(a)(4) and all associated requirements for Tier 4 in subpart C of this part (General Stationary Fuel Combustion Sources).
- (b) For each continuous glass melting furnace that is not subject to the requirements in paragraph (a) of this section, calculate and report the process and combustion CO₂ emissions from the glass melting furnace by using either the procedure in paragraph (b)(1) of this section or the procedure in paragraph (b)(2) of this section, except as specified in paragraph (c) of this section.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)