

---

## 40 C.F.R. § 62.15970

---

### Do the emission limits, emission standards, and operating limits apply during periods of startup, shutdown, and malfunction?

---

The emission limits and standards apply at all times and during periods of malfunction. The operating limits apply at all times that sewage sludge is in the combustion chamber (*i.e.*, until the sewage sludge feed to the combustor has been cut off for a period of time not less than the sewage sludge incineration residence time). For determining compliance with the CO concentration limit using CO CEMS, the correction to 7-percent oxygen does not apply during periods of startup or shutdown. Use the measured CO concentration without correcting for oxygen concentration in averaging with other CO concentrations (corrected to 7-percent O<sub>2</sub>) to determine the 24-hour average value.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)