
40 C.F.R. § 63.1389

Startups and shutdowns.

- (a) The provisions set forth in this subpart apply at all times.
- (b) You must not shut down items of equipment that are required or utilized for compliance with the provisions of this subpart during times when emissions are being, or are otherwise required to be, routed to such items of equipment.
- (c) Startup begins when the wool fiberglass glass-melting furnace has any raw materials added and reaches 50 percent of its typical operating temperature. Startup ends when molten glass begins to flow from the wool fiberglass glass-melting furnace. For cold-top electric furnaces, startup ends when the batch cover is established and the temperature of the glass batch-cover surface is below 300 °F.

This document is only available to subscribers. Please [log in](#) or [purchase access](#).

[Purchase Login](#)