

40 C.F.R. § 141.720

Inactivation toolbox components.

(a) *Calculation of CT values.* (1) CT is the product of the disinfectant contact time (T, in minutes) and disinfectant concentration (C, in milligrams per liter). Systems with treatment credit for chlorine dioxide or ozone under paragraph (b) or (c) of this section must calculate CT at least once each day, with both C and T measured during peak hourly flow as specified in §§ 141.74(a) through (b).

(2) Systems with several disinfection segments in sequence may calculate CT for each segment, where a disinfection segment is defined as a treatment unit process with a measurable disinfectant residual level and a liquid volume. Under this approach, systems must add the *Cryptosporidium* CT values in each segment to determine the total CT for the treatment plant.

(b) *CT values for chlorine dioxide and ozone.* (1) Systems receive the *Cryptosporidium* treatment credit listed in this table by meeting the corresponding chlorine dioxide CT value for the applicable water temperature, as described in paragraph (a) of this section.

CT Values (mg·min/L) for *Cryptosporidium* Inactivation by Chlorine Dioxide¹

Log credit	Water Temperature, °C										
	≤0.5	1	2	3	5	7	10	15	20	25	30
(i) 0.25	159	153	140	128	107	90	69	45	29	19	12
(ii) 0.5	319	305	279	256	214	180	138	89	58	38	24
(iii) 1.0	637	610	558	511	429	360	277	179	116	75	49
(iv) 1.5	956	915	838	767	643	539	415	268	174	113	73
(v) 2.0	1275	1220	1117	1023	858	719	553	357	232	150	98
(vi) 2.5	1594	1525	1396	1278	1072	899	691	447	289	188	122
(vii) 3.0	1912	1830	1675	1534	1286	1079	830	536	347	226	147

This document is only available to subscribers. Please log in or purchase access.

[Purchase Login](#)